Energize relay to drive CCW (OPEN)
Note:
The Position Override (ENT) control signal (line voltage hot) will drive the actuator to position determined by the controller option (Open or Closed) after a 5 second delay, thereby allowing the Position Override to override the resume normal proportional control from the signal in control.
Note: Override direction is determined by loss of signal positioning
Items within dotted line indicates internal components
Actuator ships in fully closed position!
Use For:
P2/3-120PN4-Override
WD-850-24253
ProMation
Proportional Control of FULL MOD
NONE
2/4/2015 9:38 AM
Wiring Diagram
Distribution of this document without the written consent of this owner is strictly forbidden. Failure to comply will incur a liability for damages.